


# RM6F5 Series Simple Version Operation Manual



2022.08.15 Edition XB200235

Thank you for using RHYMEBUS RM6F5 series drive.  
For proper operations and safety purposes, please read manual carefully.  
Only the qualified personnel may proceed with the installation.  
Scan the QR code on the right side for the complete operation manual.  
Please pay attention to the safety precautions marked with "DANGER" or "CAUTION" in complete manual before installation.



**⚡ DANGER** User may cause the casualty or serious damages if user does not abide by the instructions of the manual to execute the tasks.

**⚠ CAUTION** User may cause injuries to the people or damage the equipment if user does not abide by the instructions of the manual to execute the tasks.


## ■ Terminals of Main Circuit

Power Source	R, S, T (L1, L2, L3)	AC power source input terminals	Three-phase; sinusoidal power source input terminals.
	⊕, N⊖	DC power source input terminals	External DC power source terminal. ※Only 2007 ~ 2015, 4007 ~ 4020 models have the terminal.
Motor	U, V, W (T1, T2, T3)	Drive outputs to motor terminals	Output three-phase variable frequency and voltage to motor.
Power and Braking	P(+), N⊖ P, N	Dynamic brake unit terminal	Connect to dynamic braking unit(option).
	P, PR P(+), PR	External braking resistor terminal	Connect to external brake resistor (option).
	P(+), P1	External reactor terminal	Connect to DC reactor (DCL) for improving power factor. The default setting is connected by a jumper.
Grounding	PE(or G) ⊕	Grounding terminal	Ground the drive in compliance with the NEC standard or local electrical code.

## ■ Description of terminal and wiring diagram


Model : RM6F5-2001B3~RM6F5-2005B3 ;

Model : RM6F5-4001B3~RM6F5-4007B3




Model : RM6F5-2007B3 ~ RM6F5-2020B3;

Model : RM6F5-4010B3 ~ RM6F5-4030B3




Model : RM6F5-2025E3 ~ RM6F5-2100E3;

Model : RM6F5-4040E3 ~ RM6F5-4150E3



Model : RM6F5-2125E3~RM6F5-2250E3;

Model : RM6F5-4175E3~RM6F5-4700E3



※1. 125HP above drives: AC reactor (ACL) is the standard accessory;


200HP above drives: DC reactor (DCL) is the standard accessory.

Please remove the jumper between P1 and P terminal, when connecting the external DC reactor (DCL). Do Not remove the jumper, when DC reactor (DCL) does not be connected.

## ■ Control Terminal

Type	Symbol	Function	Description	
Control circuit terminal	Control power	P24	Power terminal; Output DC+24V; Maximum supplied current is 50mA.	
		P12/12V	Control device usage; Output DC+12V; Maximum supplied current is 20mA.	
		GND (COM)	Common of analog input control terminals; Common terminal for control power (P12/12V,P24) and analog input terminal (Vin, lin).	
	Input terminals	FWD	Forward command terminal	Connect the FWD and COM terminals for forward operation. (F_001=0)
		REV	Reverse command terminal	Connect the REV and COM terminals for reverse operation. (F_001=0)
		X1	Multi-function input terminal 1	<ul style="list-style-type: none"> <li>The function is set by F_052.</li> <li>Default setting: Coast to stop command</li> </ul>
		X2	Multi-function input terminal 2	<ul style="list-style-type: none"> <li>The function is set by F_053.</li> <li>Default setting: Open loop selection</li> </ul>
		X3	Multi-function input terminal 3	<ul style="list-style-type: none"> <li>The function is set by F_054.</li> <li>Default setting: Jog command</li> </ul>
		X4	Multi-function input terminal 4	<ul style="list-style-type: none"> <li>The function is set by F_055.</li> <li>Default setting: Secondary accel/decel time command</li> </ul>
		X5	Multi-function input terminal 5	Reserve
		X6	Multi-function input terminal 6	Reserve
		COM (GND)	Common of digital input control terminals	Common of digital input control signal terminals. (FWD, REV and X1 ~ X4)
		Vin	Analog input terminal	Input range: DC 0~10V ◦
		lin	Analog input terminal	<ul style="list-style-type: none"> <li>Input signal selection JP4: I position (current signal) JP4: V position (voltage signal)</li> <li>Input range: DC 4~20mA (2~10V) or DC 0~20mA (0~10V)</li> <li>The function is set by F_126.</li> </ul>
		Output terminals	FM+ AM+	Analog output terminals
	M- (GND)		Common of analog output terminals	Common of analog output terminals.
	Ta1		Multi-function output terminals (relay type)	<ul style="list-style-type: none"> <li>N.O (contact a); The function is set by F_060 .</li> <li>Default setting: Error detection</li> <li>Capacity: AC250V, 0.5A Max, cosθ=0.3</li> </ul>
	Tb1			<ul style="list-style-type: none"> <li>N.C (contact b); The function is set by F_060</li> <li>Capacity: AC250V, 0.5A Max, cosθ=0.3</li> </ul>
	Tc1			Common terminal for Ta1, Tb1.
	Ta2			<ul style="list-style-type: none"> <li>N.O (contact a); The function is set by F_061</li> <li>Default setting: Operation detection</li> <li>Capacity: AC250V, 0.5A Max, cosθ=0.3</li> </ul>
Tb2	<ul style="list-style-type: none"> <li>N.C (contact b); The function is set by F_061</li> <li>Capacity: AC250V, 0.5A Max, cosθ=0.3</li> </ul>			
Tc2	Common terminal for Ta2.			
Y1	Multi-function output terminals (open collector type)		<ul style="list-style-type: none"> <li>The function is set by F_058, F_059.</li> <li>Capacity: DC48V, 50mA Max</li> </ul>	
Y2				
CME		Common terminal of Y1, Y2.		
External Communication Terminal	DX+	Signal transmission terminal(+)	<ul style="list-style-type: none"> <li>Connect the drive by transmission cable, when the drive controls multiple pumps or RS-485 communication interface.</li> <li>Communication protocol: Modbus</li> </ul>	
	DX-	Signal transmission terminal(-)		
	GND	Grounding terminal of signal transmission	Grounding terminal of shielding wire.	

## ■ Description of Terminal and Wiring Diagram



※1.JP5: SINK / SOURCE selection;

The signal input selection of multi-function input terminal(X1~X4), FWD/REV terminals.


※2.JP4: I / V selection;

I position: lin-GND terminal is inputted with the current signal.(default)  
V position: lin-GND terminal is inputted with the voltage signal.

※3.DSW3: The terminal resistor selection for communication; The internal resistance is 100Ω.  
When external device control multiple drives, switch the DSW3 to "ON" position at the first and last drive.

※4.The analog input selection is set by F\_126 (default: DC 2~10V(4~20mA))


## ■ Voltage Selection Board of Cooling Fan



※ Above models RM6F5-4100 have the voltage selection board shown in above figure when removing the main circuit terminal cover of the drive. Please carefully select the jumper position according to the power source(actual power voltage level) to avoid the burnout of the fan or the overheating of the drive.(EX: When the power source is 460V, selecting the position from 380V to 460V)

## ■ Wiring Diagram and Setting for Single-pump and Multi-pump Applications

### Single Pump Control(F\_015=1)




1. JP4: I position
2. JP1: Open
3. DSW3: ON position
4. F\_015=1

JP4: Input signal type selection of lin  
 JP1: Input impedance selection of lin  
 DSW3: Terminal resistor switch  
 F\_015: Selection of Pump Control Mode  
 F\_016: Set Drive's No for Parallel Control


### Multi-Pump Control(F\_015=2,3,4)

#### 1. Parallel control for four pumps with four pressure transmitters (standard wiring)




1. JP4: Drive #0 ~ #3 → I position
2. JP1: Drive #0 ~ #3 → open
3. DSW3: Drive #0 and Drive #3 → ON position; Drive #1 and #2 → 1 position
4. Set the number for every drive by F\_016

#### 2. Parallel control for four pumps with one pressure transmitter (special wiring)




1. JP4: Drive #0 → I position; Drive #1 ~ #3 → V position
2. JP1: Drive #0 → open; Drive #1 ~ #3 → close
3. DSW3: Drive #0 and Drive #3 → ON position; Drive #1 and #2 → 1 position
4. Set the number for every drive by F\_016

#### 3. Parallel control for four pumps with one pressure transmitter (special wiring)




1. JP4: Drive #0 → I position; Drive #1 ~ #3 → V position
2. JP1: Drive #0 → open; Drive #1 ~ #3 → close
3. DSW3: Drive #0 and Drive #3 → ON position; Drive #1 and #2 → 1 position
4. Set the number for every drive by F\_016

## ■ Digital Type Keypad (KP-605)



## ■ Operation of Keypad


The operation of the digital keypad includes fault messages and three modes. The switching methods are shown as below figure:




The operation steps are shown as below table (by default setting)

Operation Steps	Display
1. Start the drive and enter the monitor mode.	
2. Press <b>PROG</b> key and enter the function setting mode.	
3. Press <b>FUN DATA</b> key and enter the parameter setting mode.	
4. Press <b>FUN DATA</b> key and return to the function setting mode.	
5. Press <b>PROG</b> key and return to the monitor mode.	

## ■ Description of Monitor Mode

There are eight displays can be selected in the monitor mode. Press  to switch the display in accordance with below sequence under monitor mode. User can determine one of eight displays as the main display from function F\_006 (Selection of Main Display). Please refer to the following illustrations:



- Select one of eight displays as the main display from function F\_006 (Selection of Main Display).
- Determine one of eight displays as the main display according to the application. When the parameter of function is completed without pressing key, the drive will automatically switch back to the main display after 3 minute.

## ■ Parameter List

Func.	Name	Description	Range of Setting	Unit	Default																															
F_000	Drive Information	0: Software version 1: Drive model number 2: Drive running hours 3: Drive supply power time 4: Software checksum code 5: Reserved	—	—	—																															
F_001	Start Command Selection	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th></th> <th>Start command</th> <th>Rotation direction command</th> </tr> </thead> <tbody> <tr> <td>0:</td> <td>FWD or REV terminal</td> <td>FWD or REV terminal</td> </tr> <tr> <td>1:</td> <td>FWD terminal</td> <td>REV terminal</td> </tr> <tr> <td>2:</td> <td rowspan="3">Keypad "AUTO RUN" key</td> <td>FWD, REV terminal</td> </tr> <tr> <td>3:</td> <td>Forward direction</td> </tr> <tr> <td>4:</td> <td>Reverse direction</td> </tr> <tr> <td>5~7:</td> <td>Reserved</td> <td>Reserved</td> </tr> <tr> <td>8:</td> <td>Communication interface</td> <td>Communication interface</td> </tr> <tr> <td>9:</td> <td>Communication interface</td> <td>REV terminal</td> </tr> <tr> <td>10:</td> <td>FWD terminal</td> <td>Communication interface</td> </tr> <tr> <td>11:</td> <td>Keypad "AUTO RUN" key</td> <td>Communication interface</td> </tr> </tbody> </table>		Start command	Rotation direction command	0:	FWD or REV terminal	FWD or REV terminal	1:	FWD terminal	REV terminal	2:	Keypad "AUTO RUN" key	FWD, REV terminal	3:	Forward direction	4:	Reverse direction	5~7:	Reserved	Reserved	8:	Communication interface	Communication interface	9:	Communication interface	REV terminal	10:	FWD terminal	Communication interface	11:	Keypad "AUTO RUN" key	Communication interface	0~11	—	3
	Start command	Rotation direction command																																		
0:	FWD or REV terminal	FWD or REV terminal																																		
1:	FWD terminal	REV terminal																																		
2:	Keypad "AUTO RUN" key	FWD, REV terminal																																		
3:		Forward direction																																		
4:		Reverse direction																																		
5~7:	Reserved	Reserved																																		
8:	Communication interface	Communication interface																																		
9:	Communication interface	REV terminal																																		
10:	FWD terminal	Communication interface																																		
11:	Keypad "AUTO RUN" key	Communication interface																																		

Func.	Name	Description	Range of Setting	Unit	Default
F_002	Frequency Command Selection	0: Frequency command by analog signal 1: Frequency command by keypad. 2: Pressure command by keypad. 3: Frequency command by communication. 4: Pressure command by communication. 5: Pressure command by analog signal 6: Frequency command by Pot on the keypad 7: Pressure command by Pot on the keypad	0~7	—	2
F_003	Selection of "STOP" Key Validity	0: Start command by terminal, "STOP" key disabled. 1: Start command by terminal, "STOP" key enabled.	0,1	—	1
F_004	Setting Value(SV) Selection	0: In the monitor mode, setting value cannot be changed. 1: In the monitor mode, setting value can be changed.	0,1	—	1
F_005	Auto-Storing of Setting Value Selection	0: In the monitor mode, setting value auto-storing disable. 1: In the monitor mode, setting value auto-storing after 3 minutes.	0,1	—	1
F_006	Selection of Main Display	Select 1 of 8 "monitor modes" as the main display.	1~8	—	7
F_007	Pressure Transducer Setting	Set upper limit value of pressure in accordance with pressure transducer specification.(pressure setting value is corresponding to maximum voltage or current.	0.0~160.0	bar	10.0
F_008	Maximum Allowable Operating Pressure	Set the maximum operating pressure value (F_007*F_008) in accordance with the specification of pump.	0~100	%	100
F_009	Starting Frequency	The starting frequency of drive.	0.1~10.0	Hz	0.5
F_010	Starting Voltage	The voltage corresponds to the starting frequency.	0.1~50.0	V	8.0 (Note1)
			0.1~100.0		12.0 (Note2)
F_011	Base Frequency	The frequency corresponds to the base voltage in V/F pattern.	0.1~400.0	Hz	60.0
F_012	Base Voltage	The voltage corresponds to the base frequency in V/F pattern.	0.1~255.0	V	220.0 (Note1)
			0.1~510.0		380.0 (Note2)
F_013	Selection of Pump Shift Operation (Parallel control)	0: Disable. 1: Shift the pump operation arriving the operating time (F_024). 2: Shift the pump operation after a drive stops. 3: Both 1 and 2 enabled.	0~3	—	3
F_015	Control Mode Selection (Parallel control)	0: Disable the functions related to pump. 1: Single pump application. 2: Multi-pump applications; (E-mode) 3: Multi-pump applications; (F-mode) 4: Multi-pump applications; (M-mode) 5: Multi-pump applications; (S-mode) 6: Air conditioning multiple control. 7: Proportional feedback control.	0~7	—	1
F_016	Set Drive's No. for Parallel Control	Set the individual number for every drive. #0 as the lead drive to command others.	0~7	—	0
F_017	Maximum Output Frequency	The maximum output frequency of drive.	0.1~120.0	Hz	60.0
F_018	Reference Frequency of Accel/Decel Time	The frequency corresponding to accel/decel time.	0.01~120.00	Hz	60.00
F_019	Primary Acceleration Time	The acceleration time from stop to reference frequency.	0.0~3200.0	sec	1.0
F_020	Primary Deceleration Time	The deceleration time from reference frequency to stop.	0.0~3200.0	sec	1.0






Func.	Name	Description	Range of Setting	Unit	Default
F_021	Launch Detection Time (Parallel Control)	In multi-pump control systems, If the pressure decreasing gradually, set the detection time to launch auxiliary drive.	0.0~25.0	sec	6.0
F_022	Launch Detection Level (Parallel Control)	In multi-pump control systems, set the detection level when the pressure decreasing gradually.	0.0~25.0	bar	0.4
F_023	Cut-off Frequency (Parallel Control)	In multi-pump control systems, set the cut-off frequency and start frequency for lead/auxiliary drive stopping.	0.0~60.0	Hz	50.0
F_024	Pump Auto Shift Time (Parallel Control)	The time of pump shift operation in multi-pumps control system.	0~240	hr	24
F_025	Cut-off Time (Parallel Control)	In multi-pump control systems, the detection time of pump departs from operation.	0.0~25.0	sec	10.0
F_026	Communication Baud Rate (Parallel Control)	The communication baud rate setting for multi-pump control systems.	0~3	—	1
F_027	Secondary Acceleration Time	Switch to secondary acceleration time by multi-function input terminal.	0.0~3200.0	sec	0.5
F_028	Secondary Deceleration Time	Switch to secondary deceleration time by multi-function input terminal.	0.0~3200.0	sec	0.5
F_029	Set S-curve for Accel/Decel Time	Set S-curve to slow the acceleration and deceleration time at start and stop.	0.0~5.0	sec	0.0
F_030	V/F Pattern Selection	0: Linear 1: Square curve. 2: 1.7 <sup>th</sup> power curve. 3: 1.5 <sup>th</sup> power curve.	0~3	—	1
F_031	Primary Speed	Jog command      Multi-speed level 3 command      Multi-speed level 2 command      Multi-speed level 1 command	0.00~120.00	Hz	0.00
F_032	Preset Speed 1	OFF      OFF      OFF      ON			20.00
F_033	Preset Speed 2	OFF      OFF      ON      OFF			25.00
F_034	Preset Speed 3	OFF      OFF      ON      ON			30.00
F_035	Preset Speed 4	OFF      ON      OFF      OFF			45.00
F_036	Preset Speed 5	OFF      ON      OFF      ON			50.00
F_037	Preset Speed 6	OFF      ON      ON      OFF			55.00
F_038	Preset Speed 7	OFF      ON      ON      ON			60.00
F_039	Jog Speed	ON      X      X      X			7.00
F_040	Vin Gain	Analog input "Vin" gain ratio adjustment.			0.00~2.00
F_041	Vin Bias	Analog input "Vin" bias ratio adjustment.	-1.00~1.00	—	0.00
F_042	Frequency Upper Limit	The upper limit of output frequency= F_017(Maximum Output Frequency)*F_042	0.00~1.00	—	1.00
F_043	Frequency Lower Limit	The lower limit of output frequency=F_017(Maximum Output Frequency)*F_043	0.00~1.00	—	0.00
F_044	Analog Output Signal Selection (FM+)	0:Output frequency 1:Frequency command 2:Output current 3:"Vin" analog input signal 4:"lin" analog input signal	0~4	—	0
F_045	Gain(FM+)	Analog output gain ratio adjustment.	0.00~2.00	—	1.00
F_046	Motor Overload Protection (OL)	0: Disable 1: Overload protection for dependent cooling fan type motor: Enabled(OL) 2: Overload protection for independent cooling fan type motor: Enabled(OL)	0~2	—	1
F_047	Filter Setting of Analog Input Signal	Filter the analog input signal when the frequency command is controlled by analog input. (F_002=0).	0~255	—	20
F_048	Motor Rated Current	Set the value according to the motor rated current.	10%~150% of drive rated current	A	According to the rated current of motor

Func.	Name	Description	Range of Setting	Unit	Default
F_049	Motor No-Load Current	Set the value according to the motor's no-load condition.	0~motor rated current	A	1/3 motor rated current
F_050	Motor Slip Compensation	According to the load condition, set the compensation for motor running at constant speed. (0.0: off)	-9.9~10.0	Hz	0.0
F_051	Operation Condition Memory	Record the last status of drive before power off. 0: Enable (F_001=2,3,4) 1: Disable	0,1	—	0
F_052	Multi-function Input Terminal (X1)	=0: Manual control command 1 of M-mode (F_015=4)	-23~ +23 (Note 3)	—	9
F_053	Multi-function Input Terminal (X2)	=0: Manual control command 2 of M-mode (F_015=4)			13
F_054	Multi-function Input Terminal (X3)	=0: Manual control command 3 of M-mode (F_015=4)			1
F_055	Multi-function Input Terminal (X4)	=0: Reserve			2
F_058	Multi-function Output Terminal (Y1)	0: Disable ±1: Standby detection ±2: Constant speed detection. ±3: Zero speed detection. ±4: Frequency detection.			-18 ~+18 (Note 7)
F_059	Multi-function Output Terminal (Y2)	±5: System overload detection. (OLO) ±6: Stall prevention detection. ±7: Low voltage detection. (LE) ±8: Braking detection. ±9: Restart after instantaneous power failure detection.	2		
F_060	Multi-function Output Terminal (Ta1,Tb1)	±10: Restart after error condition detection ±11: Error detection. ±12: Overheating warning detection. (Ht) ±13: Over pressure detection. (OP)	-11		
F_061	Multi-function Output Terminal (Ta2/Tc2)	±15: Auxiliary pump 1 detection. ±16: Auxiliary pump 2 detection. ±17: Fan detection during operation. ±18: PTC overheating warning detection	-3		
F_062	Frequency Detection Range	Set the bandwidth of frequency detection range.	0.0~10.0	Hz	
F_063	Frequency Detection Level	Set the frequency detection level of multi-function output terminal.	0.0~120.0	Hz	0.0
F_064	Automatic Torque Compensation Range	According to the load condition, adjust the output voltage of the V/F pattern. (0.0: off)	0.0~25.5	—	1.0

Func.	Name	Description	Range of Setting	Unit	Default
F_065	System Overload Detection (OLO)	0: Disable 1: Enable	0,1	—	0
F_066	System Overload Detecting Selection	0: Detection during constant speed only 1: Detection during operation only	0,1	—	0
F_067	Output Setting after System Overload	0: Drive keeps operation when "OLO" is detected 1: Drive trips to protection when "OLO" is detected	0,1	—	0
F_068	System Overload Detection Level	When the output current of drive is higher than the level (F_068 * drive's rated current) with the duration of F_069, the drive will trip to protection.	30%~160% of drive rated current	%	160
F_069	System Overload Detection Time		0.1~25.0	sec	2.0
F_070	Stall Prevention Level at Acceleration	If stall is occurred during acceleration, the motor keeps running at constant speed. (200%: off)	30%~160% of drive rated current	%	140
F_071	Stall Prevention Level at Constant Speed	If the stall is occurred during constant speed, the motor decreases the speed.(200%: off)	30%~160% of drive rated current	%	130
F_072	Acceleration Time Setting after Stall Prevention under Constant Speed	Set the acceleration time after stall prevention under the constant speed.	0.1~3200.0	sec	15.0
F_073	Deceleration Time Setting for Stall Prevention under Constant Speed	Set the deceleration time at the stall prevention under the constant speed.	0.1~3200.0	sec	15.0
F_074	Stall Prevention Setting at Deceleration	0: Disable 1: Enable	0,1	—	1
F_075	DC Braking Level	Set the current level of DC braking.	0~120% of drive rated current	%	50
F_076	Time of DC Braking after Stop	Set the time for DC braking after drive stopped.	0.0~20.0	sec	0.5
F_077	Time of DC Braking before Start	Set the time for DC braking before drive started.	0.0~20.0	sec	0.0
F_078	Operation Selection at Instantaneous Power Failure	0: Drive cannot be restarted 1: Drive can be restarted	0,1	—	0
F_079	Auto-Restarting Selection for Error Trip Condition	0: Short time interval to auto-restart according to the setting of F_080 (OC,OE,GF only). 1: Long time interval to auto-restart according to the setting of F_080 and F_083(all errors except Fb Lo).	0,1	—	1
F_080	Maximum Reset Time of Auto-Restart at Drive's Error Trip	Set the counting number for drive auto-restart when errors occur.	0~16	—	10
F_081	Switching Frequency	The setting value is higher and the motor noise is lower.	0~6	—	1
F_082	Stop Mode	0: Ramp to stop 1: Coast to stop 2: Coast to stop+ DC braking	0~2	—	0
F_083	Time Interval before Auto-Restart	Set the error tripping time interval before drive auto restarts for F_079 when the drive trips to stop.	1~200	10sec	6
F_084	Pressure Boost (Water Usage Detection)	Boost the pressure up to detect if the water is used.	0.01~1.00	bar	0.15
F_085	Time Interval of Pressure Boost (Water Usage Detection)	Set the time interval for F_084 to detect if the water is used. (0: off)	0~250	sec	35
F_086	(ON/OFF Mode) Starting Rate Setting	In constant pressure control mode and under low flow condition, setting the starting rate of drive to activate ON/OFF mode. (0: disable)	0~100	%	0
F_087	(ON/OFF Mode) Pressure Dead Band Setting	In ON/OFF mode, drive will auto start/stop the pump in accordance with the setting value. *Start level=SV(Setting pressure) - F_087 Stop level=SV(Setting pressure) + F_087	0.1~25.0	bar	0.3

Func.	Name	Description	Range of Setting	Unit	Default
F_088	Speed Tracing Current Level	When the current is higher than the "speed tracing current level", the output frequency will trace downward.	0~160% of drive rated current	%	150
F_089	Delay Time before Speed Tracing	Set the delay time before the speed tracing and coast stop+ DC braking.	0.1~5.0	sec	0.5
F_090	The V/F Pattern of Speed Tracing	Set the percentage of V/F output voltage at the speed tracing.	0~100%	%	100
F_091	Error Record	Display the latest 5 error records.	—	—	—
F_092	Parameter Setting Lock	0: Parameters are changeable. Maximum frequency cannot exceed 120.0Hz. 1: Parameters are locked. Maximum frequency cannot exceed 120.0Hz. 2: Reserved 3: Reserved	0~3	—	0
F_093	Automatic Voltage Regulation (AVR)	0: Disable 1: Enable	0,1	—	1
F_094	Drive Overload (OL1)	0: Disable 1: Thermal protection 2: Current limit overload protection 3: Both 1 and 2 enable	0~3	—	3
F_095	Power Source	Set the value according to the actual power source.	190.0~240.0 340.0~480.0	V	220.0 (Note1) 380.0 (Note2)
F_096	Analog Frequency Dead Band	When the signal noise is large, appropriately increase the dead band to stabilize the frequency. But this will reduce the tuning linearity.	0.00~2.55	Hz	0.00
F_097	Digital Input Response Time	When the digital input signal is under the setting time, program will not be activated.	1~16	ms	10
F_098	Grounding Fault Protection (GF)	0: Disable 1: Enable(GF)	0, 1	—	1
F_099	External Indicator 1	Select the monitor mode of external indicator 1 0: Disable	0~10	—	1
F_100	External Indicator 2	Select the monitor mode of external indicator 2 0: Disable	0~10	—	5
F_101	External Indicator 3	Select the monitor mode of external indicator 3 0: Disable	0~10	—	2
F_102	PID Compensation Gain	Compensate the gain for pressure command control under constant pressure control.	0.1~8.0	—	1.0
F_103	PID Control Mode Selection	0: Open-loop operation 1: Forward control; D postposition 2: Forward control; D preposition 3: Reverse control; D postposition 4: Reverse control; D preposition	0~4	—	1
F_104	P Selection	0: P postposition 1: P preposition	0,1	—	1
F_105	Proportional Gain(P)	Set the gain value for deviation adjustment. (0.0: P control disabled)	0.0~25.0	—	3.0
F_106	Integration Time(I)	Set the integration time for deviation adjustment. (0.0: I control disabled)	0.0~25.0	sec	1.2
F_107	Derivative Time(D)	Set the derivative time for deviation adjustment. (0.00: D control disabled)	0.00~2.50	sec	0.00
F_108	Derivative Time of Feedback	Set the derivative time for feedback signal.	0.00~2.50	sec	0.00
F_109	Integration Upper Limitation	Set the upper limitation value of integrator.	0~200% of maximum frequency	%	100
F_110	Integration Lower Limitation	Set the lower limitation value of integrator.	-100~100% of maximum frequency	%	0
F_111	Offset Adjustment for Integration Time	Adjust the integration time offset.	-100~100% of maximum frequency	%	65

Func.	Name	Description	Range of Setting	Unit	Default		
F_112	PID Buffer Space	Set the buffer space of PID output value.	0~255	—	2		
F_113	Feedback Signal Filter	Filter the feedback signal.	0~255	—	10		
F_114	Feedback Signal Trip Detection	0: Disable 1: Enable (at F_126=0)	0,1	—	1		
F_115	(Water Usage) Pressure Boost Time	Set the time of F_084 (Pressure Boost for Water Usage Detection) to detect if the water is used.	0.1~25.0	—	0.6		
F_116	Parameter Selection	0: F_000 ~ F_134 1: F_000 ~ F_194	0,1	—	0		
F_117	PID Start Range	In constant pressure control mode (F_103≠0), drive will activate PID control when the feedback signal exceeds the dead band.	0.0~10.0	bar	0.3		
F_118	(Water Shortage Detection) Auto-restart Selection	0: Disable 1: Trip (Fb Lo): Press "RESET" key to reset. 2: Trip (Fb Lo): Power ON again to reset. 3: Trip (Fb Lo): Drive will auto-restarts according to the setting of F_122 (Drive Shutdown Time for Water Shortage)	0~3	—	1		
F_119	(Water Shortage Detection) Pressure Level	Set the pressure level to detect if pump suffers from water shortage conditions. (0: Disable)	0~100% of pressure command	%	40		
F_120	(Water Shortage Detection) Current Level	Set the current level to detect if pump suffers from water shortage conditions. (0: Disable)	0~100% of motor rated current	%	0		
F_121	(Water Shortage Detection) TimeDetection	Set the detection time for F_119 and F_120 to detect if a pump suffers from water shortage.	0~250	sec	60		
F_122	(Water Shortage) Drive Shutdown Time	Drive will auto-restart after the time setting, when a pump suffers from water shortage. F_118 =3. (0:off)	0~200	min	5		
F_123	Analog Input Selection	F_103=0	Vin: Frequency command lin: Feedback signal	0~3	—	0	
		0					Vin+lin
		1					Vin-lin
		2					lin-Vin
		3					Vin or lin (switch by multi-function input Terminal X1~X4)
F_124	Proportion Type of Pressure Transducer	0: Direct proportion signal. 1: Inverse proportion signal.	0,1	—	0		
F_125	Speed Command Source Selection under Open- Loop Condition	In the closed-loop control, select the speed command source when PID is disabled by multi-function input terminal. [ multi-function input terminal= ±13 (F_103≠0) or press  ] 0: Analog input terminal (Vin). 1: Keypad  or  key setting 2: Keypad knob 3: RS-485 Communication interface	0~3	—	1		
F_126	lin Range Selection	0: 4~20mA (2~10V) 1: 0~20mA (0~10V)	0,1	—	0		
F_127	lin Gain (Analog Input)	The gain ratio of analog input terminal lin.	0.00~2.00	—	1.00		
F_128	lin Bias (Analog Input)	The bias ratio of analog input terminal lin.	-1.00~1.00	—	0.00		

Func.	Name	Description	Range of Setting	Unit	Default
F_129	AM+ Analog Output Signal Selection	0: Output frequency. 1: Frequency command. 2: Output current. 3: Vin frequency command. 4: lin frequency command.	0~4	—	2
F_130	Gain (AM+)	AM+ analog output adjustment ratio.	0.00~2.00	0.01	1.00
F_131	Constant Speed Detection Range	Set the bandwidth of constant speed detection range.	0.0~10.0	0.1Hz	2.0
F_132	DC Braking Frequency at Stop	Active frequency level of DC braking at stop.	0.1~60.0	0.1Hz	0.5
F_133	(Water Usage Detection) Drive Standby level	When the frequency during the operation is lower than the setting value, drive will decelerate to 0Hz and entering stand by status.	0~120	Hz	10
F_134	Default Setting	0: Disable CLF: Clear fault records dEF60: Restore the default value of drive for 60Hz. dEF50: Restore the default value of drive for constant pressure setting (single pump) dEF51: Restore the default value of drive for constant pressure setting (machine tool) SAv: Save the setting value. rES: Restore the setting value. rd_EE: Read the parameters from drive to digital keypad Wr_EE: Write the parameters from digital keypad to drive Cpy: In multi-pump control system, copy lead drive's parameter.	—	—	0
F_135	Set Standby Drives	In multi-pump control systems, setting the drives standby numbers.	0~7	—	0
F_136	Noise Prevention	0: Disable. 1: Enable.	0,1	—	0
F_137	Delay Time at Pump Shift Operation	The delay time setting is to remain the stable pressure of the system at the interchanging of the pump operation.	0~250	sec	10
F_138	200% Current Limit	0: Disable. 1: Enable.	0,1	—	0
F_139	Analog input selection (Vin)	0: Frequency command 1: PTC temperature	0,1	—	1
F_140	NTC Thermistor	0: Disable. 1: Enable.	0,1	—	1
F_141	Drive Overheating Warning Selection	0: Disable 1: Warning (Ht): Continue operation. 2: Warning (Ht): Drive de-rates the switching frequency automatically per 5 minutes. 3: Warning (Ht): Stop operation.	0~3	—	0
F_142	Drive Overheating Warning Level	Set the warning level to prevent drive overheating.	45~85	1°C	70
F_143	Drive Overheating Dead Band	Set the temperature dead band of F_142 and F_145.	2.0~10.0	0.1°C	3.0
F_144	Fan Control Selection	0: Forced air: Start the fan at power ON. 1: Operation air: Start the fan at running. 2: Temperature level setting: Start the fan according to the setting of F_145.	0~2	—	1
F_145	Temperature Level of Fan Activation	Set the temperature level of fan activation.	25~60	1°C	50
F_146	Minimum Operation Time of Fan	Set the minimum operation time of fan when the fan stops.	0.1~25.0	0.1min	0.5
F_147	Over Pressure Disposal	0: Disable 1: Alarm: Drive keeps operation. 2: Alarm: Drive stops output. 3: Error trip: Drive trips to stop.	0~3	—	0

Func.	Name	Description	Range of Setting	Unit	Default
F_148	Over Pressure Level	According to the setting value of F_007 (Pressure Transmitter Setting) to set the over pressure level.	0~100	%	100
F_149	Over Pressure of Detection Time	When the actual pressure exceeds over pressure level (F_007*F_148) with duration (F_149), the detection is activation.	0.0~25.5	sec	2.0
F_150	Continuous Water Supply Control	0:Disable 1:Enable	0,1	—	0
F_151	Set the Minimum Pumps during Operation	In parallel control system, set the minimum quantity of pumps during operation.	1~8	—	1
F_152	PTC Overheat Alarm Level	Set the alarm level of PTC Overheat.(OH1)	0.0~10.0	V	1.2
F_153	PTC Overheat Alarm Selection	0: Keep running 1: Stop running	0,1	—	0
F_154	PTC Overheat Trip Level	Set the trip level of PTC Overheat.(OH2)	0.0~10.0	V	2.4
F_155	Comm. Address	The host uses the address to send and receive messages from the drive.(0: Disable)	0~254	—	0
F_156	Baud Rate	0: 4800bps 1: 9600bps 2: 19200bps 3: 38400bps	0~3	—	1
F_157	Comm. Protocol	0: 8,N,2 1: 8,E,1 2: 8,O,1 3: 8,N,1	0~3	—	1
F_158	Comm. Overtime (Cot)	When the data transmission during communication transmission is interrupted, has no data transmitting, or delays, drive displays "Cot" message (0.0: Communication overtime disable)	0~1000	sec	0.0
F_159	Comm. Overtime Disposal	0: Warning (Cot): Continue operation. 1: Warning (Cot): Ramp to stop 2: Warning (Cot): Coast to stop	0~2	—	0
F_160	Multi-Function Input Selection	0: Multi-function inputs from multi-function terminals 1: Multi-function inputs from communication control	0,1	—	0
F_162	Frequency Upper Limitation by Manual Mode	Setting manual mode for upper limit of frequency command	0~100% maximum of output frequency	%	100
F_163	Frequency Lower Limitation by Manual Mode	Setting manual mode for lower limit of frequency command	0~100% maximum of output frequency	%	0
F_165	Pump Delay Start Time	In the PID control, when the feedback signal exceed the dead band, pump will start after the setting time.	0~9999	sec	0
F_166	K Value of Flow Sensor	Setting value accord with specification of flow sensor	0.1~100.0	L/Pulse	10.0
F_167	Rate of Flow Sensor	Setting rate of flow sensor	0.00~2.00	—	1.00
F_168	Unit of Flow Sensor	0: LPS 1: CMH	0,1	—	0
F_170	Flow Switch Detect time	When the multiple-input terminal is set to $\pm 23$ , and the trigger time is longer than the setting value. The drive will enter to ON/OFF mode automatically.	0~600	sec	15
F_171	Shutoff Head(H)	Setting shutoff head of pump	0~160	bar	12.0
F_172	Maximum Flow (Q)	Setting maximum flow of pump	0.0~6000.0	L/min	300.0
F_173	Compensation for Pipe Friction Loss	0:Disable 1:Enable	0,1	—	0
F_174	The Current in Maximum Flow ( $I_{Qmax}$ )	Setting current in maximum flow( $I_{Qmax}$ )	1~200% of drive rated current	%	100
F_175	The Current in Minimum Flow ( $I_{Qmin}$ )	Setting current in minimum flow( $I_{Qmin}$ )	0~200% of drive rated current	%	30
F_176	Pump Flow Rate Compensation for Pipe Friction Loss ( $H_{COMPmax}$ )	Setting maximum flow for pipe friction loss	0.1~160	bar	0.0

Func.	Name	Description	Range of Setting	Unit	Default
F_177	Response Time Compensation of Pipe Friction Loss	Setting pump for response time compensation of friction loss	1~255	—	40
F_180	Sequetial Operation for Start Control	0: Disable 1: Enable	0~1	—	0
F_181	Date/ Time Setting	Y: Year	2000~2099	—	—
		M: Month	1~12		
		d :Day	1~31		
		W: Week	Sun.7~SAT.6		
		H: Hour	0~23		
	MM: Minute	0~59			
F_182	Date/ Time Display	Y: Year M: Month d: Day W: Week H: Hour MM: Minute -----: Reserved	—	—	—
F_183	Sequential Operation Mode	0: Every week 1: Every day	0,1	—	0
F_184	Sector 1 Sequential Operation	S: Level selection	OFF,ON	—	OFF
		W: Week	Sun.7~SAT.6	—	Sun.7
		Sun.7: Sunday			
		Mon.1: Monday			
		TUE.2:Tuesday			
		Wed.3:Wednesday			
		THU.4:Thursday			
Fri.5:Friday					
SAT.6:Saturday					
	H: Hour	0~23	hour	0	
	MM: Minute	0~59	min	0	
	C: Pressure command	0.1~160.0	bar	0.0	
	SL: Inclined time	0.1~600.0	sec	0.0	
F_185	Sector 2 of Sequential Operation	Refer to F_184 setting description	—	—	—
F_186	Sector 3 of Sequential Operation	Refer to F_184 setting description	—	—	—
F_187	Sector 4 of Sequential Operation	Refer to F_184 setting description	—	—	—
F_188	Sector 5 of Sequential Operation	Refer to F_184 setting description	—	—	—
F_189	Sector 6 of Sequential Operation	Refer to F_184 setting description	—	—	—
F_190	Sector 7 of Sequential Operation	Refer to F_184 setting description	—	—	—
F_191	Sector 8 of Sequential Operation	Refer to F_184 setting description	—	—	—
F_192	Unit of pressure setting	0: bar 1: % Note: only work in F_084 and F_117	0~1	—	0
F_193	Reduce the Switching Frequency during overloading	0: If the drive is overloaded, the swithing frequency can not be adjusted with amount of current. 1: If the drive is overloaded, the switching frequency can be adjusted with amount of current.	0~1	—	1



















Func.	Name	Description	Range of Setting	Unit	Default
F_194	Default Setting	0: Disable	-	-	0
		CLF: Clear error records			
		dEF60: Restore the default value of drive for 60Hz.			
		dEF50: Restore the default value of 60Hz single pump constant pressure control application			
		dEF52: Restore the default value of 60Hz multi-pump constant pressure control application.			
		dEF53: Restore the default value of 50Hz single pump constant pressure control application			
		dEF57: Restore the default value of 60Hz multi-pump constant pressure control (S-mode) application			
		SAv: Save the setting value.			
		rES: Restore the setting value.			
		rd_EE: Read the parameters from drive to digital keypad			
		Wr_EE: Write the parameters from digital keypad to drive			
		CPy: In multi-pump control system, copy lead drive's parameter.			

The color as  means the functions can be set during operation.















Note:

1. Specification of 200V series.
2. Specification of 400V series.
3. + : Represents a contact (N.O) — : Represents b contact (N.C)

## Error Trip Messages of Drive

Display	Description	Display	Description
<p>(EEr)</p>  <p>KEYPAD SV Running PV</p>	EEPROM error	<p>(OLO)</p>  <p>KEYPAD SV Running PV</p>	System overload
<p>(AdEr)</p>  <p>KEYPAD SV Running PV</p>	A/D converter error	<p>(thr)</p>  <p>KEYPAD SV Running PV</p>	External fault
<p>(SC)</p>  <p>KEYPAD SV Running PV</p>	Fuse open	<p>(PAdF)</p>  <p>KEYPAD SV Running PV</p>	Keypad interruption during copy
<p>(LE1)</p>  <p>KEYPAD SV Running PV</p>	Under voltage during operation	<p>(OH)</p>  <p>KEYPAD SV Running PV</p>	Drive overheating
<p>(OC)</p>  <p>KEYPAD SV Running PV</p>	Drive over current	<p>(OL)</p>  <p>KEYPAD SV Running PV</p>	Motor overload
<p>(GF)</p>  <p>KEYPAD SV Running PV</p>	Grounding fault	<p>(OL1)</p>  <p>KEYPAD SV Running PV</p>	Drive overload
<p>(OE)</p>  <p>KEYPAD SV Running PV</p>	Over voltage	<p>(ntCF)</p>  <p>KEYPAD SV Running PV</p>	NTC thermistor sensor fault
<p>(no Fb)</p>  <p>KEYPAD SV Running PV</p>	PID feedback signal error	<p>(OP)</p>  <p>KEYPAD SV Running PV</p>	Over pressure

## Warning Messages of Drive

Display	Description	Display	Description
<p>(LE)</p> 	Power source under voltage	<p>(Err_00)</p> 	Err_00: Keypad cable trip.(before connecting)
<p>(bb)</p> 	Drive output interruption	<p>(Err_01)</p> 	Err_01: Keypad cable trip.(connected)
<p>(Fr)</p> 	Coast to stop	<p>(Wr_F)</p> 	Different software version inter-copy
<p>(db)</p> 	Over voltage at stop	<p>(OP)</p> 	Over pressure
<p>(dtF)</p> 	Direction command error	<p>(Ht)</p> 	Drive overheat
<p>(PrEr)</p> 	Program fault	<p>(CPy)</p> 	Parameter copy complete
<p>(Cot)</p> 	Communication overtime	<p>(CPyF)</p> 	Parameter copy error